

Bedienungsanleitung

Einleitung

Der TCD-DownloadPocket kann Informationen von allen gängigen Marken der digitalen Tachographen sowie den Fahrerkarten herunter laden. Die kopierten Daten werden auf einem internen Speicher abgespeichert.

Der Download Prozess (Digitaler Tachpgraph / Vehicle Unit)

Bitte achten Sie darauf, dass vor jedem Download am Tachographen eine Unternehmer- oder Werkstattkarte eingesetzt werden muss. Die Zündung muss eingeschaltet sein.

Verbinden Sie den TCD-DownloadPocket mit der 6-Pin Download Buchse an der Vorderseite des Tachographen.

Achten Sie darauf, dass der TCD-DownloadPocket NIE mit einem analogen Tachographen (Tachoscheiben) verbunden werden darf.

Wird nichts ausgewählt, startet der Download automatisch, wenn nicht drücken Sie die Taste „A“. rechnen Sie damit, dass das Herunterladen möglicherweise länger als 30 Minuten dauern kann.

ACHTUNG: UNTERBRECHEN SIE NIEMALS die Verbindung mit dem TCD-DownloadPocket, dies kann Fehler in den gespeicherten Daten verursachen.


Das Herunterladen der Fahrerkarte:

Für das Herunterladen der Fahrerkarten stecken Sie die Karte mit dem Chip nach unten ein, der Download startet selbständig nach kurzer Zeit. Nach erfolgreichem Download wird die Meldung „Download Beendet“ angezeigt und ein Pieps Ton erklingt. Die Karte kann nun entfernt werden.

Mit dem TCD-DownloadPocket ist es möglich sowohl Fahrer- als auch Werkstattkarten direkt im Gerät auszulesen.

Die Datenübertragung der Daten in das Onlineportal

Schließen Sie als erstes den TCD-DownloadPocket an einen freien USB-Anschluss an. Für die Übertragung der Daten auf das Online-Portal melden Sie sich bitte unter www.tachodownload.com mit ihren Zugangsdaten an, klicken Sie dann auf

 wählen Sie dann den Wechseldatenträger TCDPocket aus. Die Dateien befinden sich im Verzeichnis: DOWNLOAD. Wählen Sie die Dateien aus die Sie hochladen möchten und drücken dann öffnen. Zum Abschluss muss noch der mit Hochladen bestätigt werden.

Stromversorgung

Das Gerät wird standartgemäß über 1 AA Batterie betrieben. Achten Sie auf die richtige Polarität, wenn Sie die Batterien einsetzen.

Für die Uhrzeit/Datum befindet sich eine Knopfzellen-Batterie im Gerät.

Weitere Funktionen / Einstellungen

Um an die Einstellungen bzw. weitere Funktionen zu gelangen, stecken eine Karte einfach mit dem Chip nach außen in den Kartenleser.

- A. Downloadeinstellungen: Kartendownload, Aktivitäten, Ereignisse. u Störungen, detaillierte Geschwindigkeit, technische Daten, Zeitraum (Alles, Anzahl der Tage, Zeit, Vom letzten Download).
- B. Datum und Uhrzeit am Gerät einstellen
- C. Geräteeinstellungen: Download Warnung, Karten Warnungen, Beeps, Dateiformat
- D. Sprachauswahl

Operating Instructions

Introduction

The TCD-DownloadPocket device can download data from all current tachograph manufacturers' vehicle units (VUs) and from the driver cards. The downloaded data from the VU is stored on an internal-memory.

VU Download Process

Please note that for any download from a digital tachograph VU a Company- or a Workshop card must be inserted first in the VU. The VUs must be switched on.

Connect the TCD-DownloadPocket to the 6-pin Download connector on the front side of the VU.

Please note that TCD-DownloadPocket should NOT be connected to an analogue (chart-recording) tachograph.

The download starts automatically if not please press the "A" button. Please note that the download from the VU could take longer than 30 minutes.

NOTE: DO NOT disconnect the TCD-DownloadPocket or remove the SD card during a download, so may cause file errors.


Driver Card Download Process

For the download from the driver cards insert the card with the chip on the lower side in the TCD-DownloadPocket. The download starts automatically in moment. After the successful download you will the Message "Download finished" and a beep will sound. The card can removed now.

With the TCD-DownloadPocket it is possible to download driver- and workshop cards.

Transfer of the downloaded data's in the web-portal

Connect the TCD-DownloadPocket on a free USB-Port from your computer. For the transfer of the files please sign in with your username and password on www.tachodownload.com then go to

 and choose the removable drive TCDPocket. You find your files in the DOWNLOAD directory. Select the files you want to upload and press open. At last you have to confirm the upload.

Power supply

The TCD-DownloadPocket is running with an AA-sized battery. Please take a look the the polarity of the battery if you are replace it. For the time/date the TCD-DownloadPocket is using a round cell battery.

Other options / setup

To get access to option / setup of the TCD-DownloadPocket insert a card up-side down in the card reader (with the chip outside)

- A. Download options: Card download, activities, events and faults, detailed speed, technical data, download range (number of days, period, from last download, all)
- B. Date and time
- C. Device setup: Download warnings, card warnings, sounds, file format
- D. Language setup.